

# PEAKFLOW PUMPS

*These 2 pictured wye and 45 fittings are included. We recommend similar Schedule 40 pressure fittings for the rest of this (and any) pump installation.*

*If your installation includes plugging the control unit into a live phone line, remember to turn "phone line monitoring" to Yes. Press/hold function display button for "M", let go, press again to toggle from N to Y.*

*We highly recommend a separate discharge pipe whenever possible. This not only increases total capacity if all pumps needed to run, and provides an alternative to a blocked or frozen pipe, but also decreases the dependance on working check valves.*

*The tighter the nuts on the battery post are, the less likely any corrosion will build.*

*Both Sensors must be higher than the intakes of **both** pumps.*

*Don't forget to drill 1/8" relief holes in discharge pipe. Angle the hole downward!*

*Use plenty of cable ties, not only for cable management, but also for strain relief.*

*for more tips and Q and A, visit:  
[www.peakflowpumps.com](http://www.peakflowpumps.com)*

